


# 4K 60Hz HDMI CAT Extender LT - 70m User's Guide



P/N: HD20Ext-LT

Thank you for purchasing from gofanco. Our products aim to meet all your connectivity needs wherever you go. For optimum performance and safety, please read the instructions carefully and keep this User's Guide for future reference. If you need more information about our products, please visit www.gofanco.com. For technical support, please email us at support@gofanco.com. For drivers/manuals download, please go to www.gofanco.com/downloads.

### **Important Safety Notices**

Please read safety instructions carefully before installation and operation.

- Please pay close attention to all warnings and hints for this device
- Do not expose this unit to rain, heavy moisture, or liquid
- Do not repair the device or open the enclosure without professional guidance to avoid electric shocks. Doing so may void your warranty
- Keep the product in a well-ventilated location to avoid damage from overheating

- Shut off power and make sure environment is safe before installation
- Do not plug the HDMI cables and IR cables in/out when the device is in use to avoid cable damage. Make sure they are plugged into the correct ports
- Use the included power adapter only. Make sure the specification matches if using 3rdparty DC power adapters

#### Introduction

The 4K 60Hz HDMI CAT Extender LT - 70m extends HDMI transmissions up to 70 meters over a single CAT6/6A/7 cable.

#### **Features**

- Extends HDMI transmissions up to 70m (230ft) at 4K and 1080p
- Supports UHD 4K/60Hz/4:4:4, HDR, 18Gbps bandwidth
- HDCP 2.2 compliant
- HDMI loop-out equipped on the TX, IR pass-through, 4K to 1080p auto scaling
- Supports audio extraction to Stereo on the RX

- Near zero latency
- Lightning/Surge/ESD protection

### **Package Contents**


- 4K 60Hz HDMI CAT Extender LT 70m (1 Transmitter & 1 Receiver)
- 1x IR Blaster cable and 1x IR Receiver cable
- 2x Power adapters (5VDC/1A)
- Surface mount accessories
- User's guide

### Installation Requirements

- 1. HDMI source device (computer, DVD player, XBOX, PS3, etc)
- 2. HDMI display device (SDTV/Monitor, HDTV/Monitor, projector, etc.)
- 3. UTP/STP CAT6/6A/7 cable following IEEE-T568B wiring standard
- 4. HDMI cables (5m max)


### **Product Layout**

#### Transmitter TX Front and Rear Panel



- 1. **Reset Button**: Press to reset the TX
- 2. **RJ45 Out**: Connects to the Receiver's RJ45 In using a CAT cable
- 3. **IR Out:** Connects to the included IR Blaster cable to control the HDMI source device from the remote display location
- 4. **Power/Signal LED**: Blinks when powered on with no HDMI signal detected, and solid on when HDMI signal is detected
- 5. **Power Jack**: Connects to the included power adapter
- 6. **HDMI Out**: Connects to an HDMI display for local monitoring of the remote display
- 7 HDMI In: Connects to your HDMI source

#### Receiver RX Front and Rear Panel



- 1. **Reset Button**: Press to reset the RX
- 2. **RJ45 In**: Connects to the Transmitter's RJ45 Out using a CAT cable
- 3. **IR** In:Connects to the included IR Receiver cable to control the HDMI source device from the remote display location
- 4. **Power/Signal LED**: Blinks when powered on with no HDMI signal detected, and solid on when HDMI signal is detected
- 5. **Power Jack**: Connects to the included power adapter
- 6. **HDMI Out**: Connects to an HDMI display
- 7. **Audio Jack**: Connect to Stereo speakers or headphones

### **CAT Cable Wiring**

We suggest both RJ45 connectors be wired identically using T568B wiring standard for the best performance and compatibility.

Both connectors must be wired identically, to T568B standard.



	Contact Side	our Code (T568B) - Tab is on Back
8	_	BROWN
7		WHITE / BROWN
5		WHITE / BLUE
4 3		BLUE WHITE / GREEN
2	_	ORANGE WHITE / ORANG


Note: You may use cat5e, cat6 UTP (cat6 preferred) in conjunction with the RJ45 output; however for best performance use cat6a or cat7 (particularly in electrically noisy environments). The maximum distances & transmission performance for HDMI and USB may be compromised by cable quality, patch panels, poor termination, wall plates, cable kinks and electrical interferences. Generally ensure the cat cable is solid copper core of 23AWG (avoid CCA type), in one straight run (avoid/minimise patches) and avoid close proximity to any noisy electrical sources.

#### Hardware Installation

- 1. Power off all devices including your HDMI source and HDMI display(s).
- 2. Connect your HDMI source device to the Transmitter's HDMI In connector with an HDMI cable (HDMI cable not included).
- 3. Optional: Connect your HDMI display to the Transmitter's HDMI Out connector with an HDMI cable (HDMI cable not included) for local monitoring of the HDMI signal.
- 4. Optional: Connect the IR Blaster cable to the Transmitter's IR Out port. Face the cable's emitter eye towards your HDMI source device's IR window. This connection is needed only if you need to control your HDMI source device from the remote display location.
- 5. Plug a CAT6 cable between the Transmitter's RJ45 Out and Receiver's RJ45 In.
- 6. Connect your HDMI display to the Receiver's HDMI Out connector with an HDMI cable (HDMI cable not included).

- 7. Optional: Connect the IR Receiver cable to the Receiver's IR In port. This connection is needed only if you need to control your HDMI source device from the remote display location.
- 8. Plug the included power adapters into the TX's and RX's power jack, then plug the power adapters into reliable power sources.
- 9. Power on all connected devices.
- 10. The HDMI extender is ready for use.

### **Application Diagram**



## **Specifications**

Items	Transmitter	Receiver		
Video				
Input interface	1x HDMI Type A Female	1x RJ45 Female		
Output interface	1x HDMI Type A Female 1x RJ45 Female	1x HDMI Type A Female		
HDMI Length	≤5m	≤5m		
Maximum transfer rate	18Gbps			
Maximum transmission bandwidth	600MHz			
EDID passthrough	Yes			
Compatibility	HDMI (4K @60Hz, YUV 4:4:4, HDR, Deep color)			
Compatibility	HDCP 2.2			
Resolutions	480i@60Hz, 480p@60Hz, 576i@50Hz, 576p@50Hz, 720p@50/60Hz, 1080i@50/60Hz, 1080p@50/60Hz, 3840x2160@24/25/30/50/60Hz, 4096x2160@24/25Hz, 1280x960, 1280x800, 1280x768, 1680x1050, 1360x768, 1366x768, 1600x900, 1024x768, 800x600			
Transmission distance	CAT6/6A/7≤70m			
Audio				
Input interface	1x HDMI Type A Female	N/A		
Output interface	1x HDMI Type A Female	1x HDMI Type A Female 1x 3.5mm L/R Female		
Audio formats	Audio formats LPCM/DTS-HD/DTS-Audio/Dolby Digital 5.1CH/Dolby Atr			
Command Signal				
IR interface	1x 3.5mm IR OUT Female	1x 3.5mm IR IN Female		
Receiving range	iving range ≤5m			
Infrared frequency	20KHz~60KHz			

#### **Disclaimer**

The product name and brand name may be registered trademarks of related manufacturers. TM and ® may be omitted on the user's guide. The pictures on the user's guide are just for reference, and there may be some slight differences with the actual products.

We reserve the right to make changes without prior notice to a product or system described herein to improve reliability, function, or design.



Thank you for choosing gofanco

www.gofanco.com