

# 2-Port HDMI 2.0 KVM with USB 2.0 User's Guide





P/N:KVMHD2

Thank you for purchasing from gofanco. Our products aim to meet all your connectivity needs wherever you go. For optimum performance and safety, please read the instructions carefully and keep this User's Guide for future reference. If you need more information about our products, please visit www.gofanco.com. For technical support, email us at support@gofanco.com. For drivers or manual download, please go to www.gofanco.com/downloads.

# Important Safety Notices

Please read safety instructions carefully before installation and operation.

- Please pay close attention to all warnings and hints for this device
- Do not expose this unit to rain, heavy moisture, or liquid
- Do not put any items into the device or attempt to modify its operation
- Do not repair the device or open the enclosure without professional guidance to avoid electric shocks. Doing so may void your warranty
- Keep the product in a well-ventilated location to avoid damage from overheating
- Shut off power and make sure environment is safe before installation
- Do not plug the HDMI cables in/out when the device is in use to avoid cable damage. Make sure they are plugged into the correct ports
- Use the included power adapter only. Make sure the specification matches if using 3rd-party DC power adapters

### Introduction

The 2-Port HDMI 2.0 KVM with USB 2.0 allows you to control two 4K computers using one set of keyboard, mouse, microphone, speaker, and display.

### **Features**

- 2-Port KVM Switch with the latest HDMI 2.0 (Video), USB Keyboard/mouse, with Stereo Out and Mic In. All cables included
- Supports up to 4K@60Hz resolution
- HDMI 2.0 compliant
- HDCP 2.2 compliant
- Includes a 2-port USB 2.0 hub
- Manual push button and keyboard hot-key device switching


# **Installation Requirements**

- HDMI computers
- HDMI display
- HDMI cables (not included)

### Package Contents

- 2-Port HDMI 2.0 KVM with USB 2.0
- HDMI cables (2pcs)
- USB 2.0 cables (2pcs)
- Audio/Mic cables (2pcs)
- Power adapter (Output: 5V/2A)
- User's guide

# **Product Layout**



**Figure 1: Front Panel Layout** 

- 1. **Microphone jack**: Connects to your microphone
- 2. **Speaker/Headphone jack**: Connects to your speaker/headphone
- 3. **HDMI out**: Connects to your HDMI display
- 4. **Reset**: Press to reset the system
- 5. **USB Type-A (x2)**: Keyboard and mouse connection
- 6. **USB Type-A (x2)**: Connects to your USB devices
- 7. **PC 2 select LED**: Lights up whe PC 2 is the selected computer
- 8. **PC 2 active LED**: Lights up when PC 2 is up and running
- 9. **Switch button**: Press to switch between the 2 computers
- 10. **PC 1 select LED**: Lights up whe PC 1 is the selected computer
- 11. **PC 1 active LED**: Lights up when PC 1 is up and running




Figure 2: Rear Panel Layout

- 1. **Power jack**: Connects to the included power adapter
- 2. **Microphone jack**: Connects to PC 1's microphone input jack
- 3. **Audio input jack**: Connects to PC 1's speaker/headphone jack
- 4. **USB Type-B:** Connects to PC 1's USB Type-A port
- 5. **HDMI in**: Connects to PC 1's HDMI output port
- 6. **Microphone jack**: Connects to PC 2's microphone input jack
- 7. **Audio input jack**: Connects to PC 2's speaker/headphone jack
- 8. **USB Type-B**: Connects to PC 2's USB Type-A port
- 9. **HDMI in:** Connects to PC 2's HDMI output port

### Hardware Installation

### Front Panel Connection

- Connect your HDMI display to the HDMI out of the KVM using an HDMI cable (HDMI cable not included).
- 2. Connect your keyboard and mouse to the keyboard and mouse ports of the KVM.
- 3. Connect your microphone and speaker/headphone to the corresponding jacks of the KVM (optional).
- 4. Connect your USB devices to the USB ports (optional).


### **Rear Panel Connection**

- 1. Using the included cables, plug the HDMI, USB, microphone, and speaker connectors into their corresponding sockets on the rear panel of the KVM.
- 2. At the other end of the cable, plug the HDMI, USB, microphone, and speaker connectors into their corresponding sockets on PC 1, then repeat for PC 2.
- 3. Plug the included power adapter into the KVM's power jack, then plug the power adapter into a reliable power outlet.
- 4. Power on all connected devices.


# **Connection Diagram**

The application diagram shows the most typical input and output devices used with the KVM.

### Front Panel Connections



# **Rear Panel Connections**



# **Operating Instructions**

### **PC** Switching

There are two ways to switch between the computers, manual push button and keyboard hot-key commands.

### Manual Push Button

Press the front panel switch button to switch between the connected computers.

# **Keyboard Hot-key**

- 1. Press the [Scroll Lock] or [Ctrl] key twice within 5 seconds to enter Hot-key mode. While in Hot-key mode the keyboard's Scroll Lock LED flashes continuously or Ctrl LED flashes instead if Scroll Lock is not available. **Note**: When entering or exiting Hot-key mode, the KVM's buzzer will sound an audible beep.
- 2. Complete the Hotkey command within 10 seconds, or the process will be aborted.

### **Hot-key Commands:**

- A. [Scroll Lock] + [Scroll Lock] + [Enter] <u>OR</u> [Ctrl] + [Ctrl] + [Enter]: Switches between the connected computers
- B. [Scroll Lock] + [Scroll Lock] + [B] + [0/1] OR [Ctrl] + [Ctrl] + [B] + [0/1]: Disables [0] or Enables [1] the KVM's buzzer.
- C. [Scroll Lock] + [Scroll Lock] + [S] <u>OR</u> [Ctrl] + [Ctrl] + [S]: Enables Auto Scan mode. Press any keyboard key or the front panel switching button to disable Auto Scan mode.
- D. [Scroll Lock] + [Scroll Lock] + [I] + [5-99] + [Enter]

  OR [Ctrl] + [Ctrl] + [I] + [5-99] + [Enter]: Sets Auto

  Scan time interval. Default Auto Scan interval is 8

  seconds.

# **Specifications**

Storage temperature	-20 to 60 C
Operating humidity	0 to 80% RH (no condensation)
HDMI compliance	HDMI 2.0
HDCP compliance	HDCP 2.2
Video format	Ultra HD, 4K@60Hz (max)
Control	Front panel buttons, keyboard hot-key
Power adapter	Input: 100-240 VAC, 50/60Hz, 0.4A Output: 5V, 2A
Dimensions (mm)	167 (W) x 84 (D) x 32 (H)

Blank Page

### **Disclaimer**

The product name and brand name may be registered trademarks of related manufacturers. TM and ® may be omitted on the user's guide. The pictures on the user's guide are just for reference, and there may be some slight differences with the actual products.

We reserve the right to make changes without prior notice to a product or system described herein to improve reliability, function, or design.



Thank you for choosing gofanco

www.gofanco.com